
Interface Description

The interface transmitter is designed to translate paging commands from a host computer to signals understood by LRS Pagers


Transmitter Installation

- 1. Unpack the system. Be sure the following items are found:
 - · Interface unit
 - · Computer serial interface cable
 - 12-VDC wall adapter
 - · Antenna with right angle elbow
- 2. Connect the antenna.
- 3. Plug the 12-Volt power adapter into a wall outlet.
- 4. Plug the power supply into the interface transmitter.
- 5. Connect the serial cable from the connector on the interface transmitter to the serial port on the host computer.
- 6. The unit is ready for operation.
- 7. Refer to the user manual available online at support.lrsus.com.



REPEATER OPERATION

If your transmitter has been configured as a repeater, place it somewhere that is still within the transmit range of the other paging transmitter. This will allow the LRS pagers to receive pages beyond the normal range of your paging transmitter.



Note: Previous hardware revisions of the T7471-C232 would deliver 5 VDC on pin 9 of the DE-9 serial connector. Please be advised that current hardware revisions no longer do this.

SYSTEM SPECIFICATION

Required Voltage: One 110V outlet for the interface transmitter

Operating Frequency: 467.750 MHz Radiated Power <4900 micro-volts/meter

Operating Range: Dependent upon pagers, topography and environment

Long Range Systems, LLC reserves the right to make changes without further notice to any products herein. Long Range Systems, LLC makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Long Range Systems, LLC assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Long Range Systems, LLC data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Long Range Systems, LLC products are not designed, intended, or authorized for use as components in systems intended to support or sustain life, or for any other application in which the failure of the Long Range Systems, LLC product could create a situation where personal injury or death may occur.

Should Buyer purchase or use Long Range Systems, LLC products for any such unintended or unauthorized application, Buyer shall indemnify and hold Long Range Systems, LLC and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Long Range Systems, LLC was negligent regarding the design or manufacture of the part, device or system.

FCC STATEMENT

- 1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
 - (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
- 2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
 - NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF Exposure Guidance

In order to comply with FCC / ISED RF Exposure requirements, this device must be installed to provide at least 20 cm separation from the human body at all times.

Afin de se conformer aux exigences d'exposition RF FCC / ISED, cet appareil doit être installé pour fournir au moins 20 cm de séparation du corps humain en tout temps.